

# Manage Data on Mobile Devices and PC



## GENNECT Cross

Verify the data captured by your test equipment on mobile devices in real time. The app downloads the measured data from the test tool using Bluetooth® wireless technology, letting you check, save, and create reports right on your smartphone or tablet.



Dedicated website



Review and record data and create reports



- 1 Take a picture of the test site, record measured values right on the image, and make additional comments.
- 2 Capture and present current and voltage waveforms, and even conduct FFT analysis.
- 3 Display the measured values shown on the instrument in real time on your smartphone.
- 4 Measured values are saved automatically at the set recording interval. You can review maximum, minimum, and average values for the recorded period.
- 5 PASS/FAIL determinations are color-coded for easy identification.
- 6 Capture a drawing as in image in the app and record measurement results on the drawing.
- 7 Calculate and display harmonic levels for individual orders, content percentages, and total harmonic distortion (THD-F and THDR).
- 8 You can use saved data and photographs to create reports.

### Supported instruments



### Downloading GENNECT Cross

Data can be downloaded to tablets and smartphones using Hioki's dedicated apps available from the Google Play or App Store. Search for "HIOKI" and download the "GENNECT Cross" app.

